



COUNTDOWN CHECKLIST 13 Insert your selected engine into the aft section. Use masking tape around the engine to assure a snug fit. Insert igniter into the engine nozzle per the instructions which came with the engines. 12Pack one square of wadding into the aft section over the engine. 11 Roll up the streamer and insert it into the upper body, slip the two body segments together. ☐ 1□ Remove the safety interlock key from the launch control panel. (If a simple spring switch is used, install the protector around the spring.) Carry the key or interlock on the person of the launch control officer. 9 Place the rocket on the launcher. Check to be sure the panel is disarmed. Clean the micro-clips and attach them to the igniter. 8 Clear the launch area, alert the recovery crew and trackers. **7** Check for low flying aircraft and unauthorized persons in recovery area. 6 Arm the launch panel. T minus LAUNCH! Your Astron Mark II is designed for high performance. For best results we recommend making your first flights with 1/2A engines to minimize the chance of losing the model. Because of its high altitude performance, fly the Mark II on calm, clear days. Launch your model using standard electrical launching system with a 1/8" diameter guide rod at least 18" long.

Astron MARK III K-2





PARTS LIST

BNC-30-E BT-30-A BT-30-J JT-30-C SC-1B SM-1A TD-1A

KD-2A


3.5" Tube
2.75" Tube
Coupler
Shock Cord
Streamer
Tape Disc

Decal Sheet

Nose Cone

BF-2 Die Cut Fins
LL-2A Launch Lug
SCM-30 Shock Cord Mount
In addition to the parts listed you

In addition to the parts listed, you will need, white glue, sandpaper, scissors, pencil or pen and sanding sealer and paint.




FINISHING TOUCHES

Before finishing let all the glue dry so it is hard and clear. Sand fins and nose cone smooth with fine sandpaper. Paint the balsa parts with sanding sealer, let dry and sand lightly. Repeat until all grain pores disappear.

Spray the entire rocket with bright yellow paint. Use several light coats. Spray the aft tube gloss black after masking the fins.

Cut out the decals from decal sheet KD-2A. To transfer dip the decal in lukewarm water for about 30 sec. or until it slides easily on the backing paper. Slide the decal off the paper onto its desired location and blot carefully. Allow the decals to dry for about 24 hours then spray entire model with clear enamel. (Do not use model dope.)

2CW-30 TNUOM зноск сово SEC' I SEC' 5 **SEC, 3** SHIST 2CM-30 THUOM гноск сово SEC' I SEC. 2 SEC. 3 53153



J Juch

1 Inch

ESTES

37030

1 Inch



INTERCEPT OF THE PROPERTY OF THE PROPERTY