





110 lb. Cardstock

Cut Out Blue Areas.

Cut skewers to 5.2" long.

BT-5 is 3" long.

Mars Scout

- Cut out and fold on lines
- Cut out landing pads and glue in sets of TOP and BOTTOM
- Insert bamboo skewers for landing legs
- Glue completed landing pads on legs
- Roll an engine mount or use a BT-5.
- Insert engine mount using circles to center. GLUE SECURELY.
- Install an engine block so $\frac{1}{4}$ " of engine extends from bottom of mount.
- Poke holes for the launch rod.

300
DPI

No.0303SR

THE L.S. STARNETT CO.
ATHOL, MASS., U.S.A.



