


TORRELLIAN INVAIDER

SKILL LEVEL 3 - Recommended for Craftsman Rocketeer.

BEFORE YOU START

Read all instructions before beginning work on your model. Make sure you have all parts and materials. When you are thoroughly familiar with the assembly procedure, begin construction. Check off each step as you complete it. In each step, test-fit the parts together before applying any glue. If some part doesn't fit properly, sand lightly or build-up as needed for precision assembly.



PARTS LIST KIT NO. 1343

A	1	Engine Mount Tube (type BT-20J) . . .	30326
B	1	Engine Hook (type EH-2)	35025
C	1	Hook Retainer Ring (type HR-20) . . .	30168
D	1	Split Adapter Ring (type AR-2050S) .	80425
E	1	Adapter Ring (type AR-2050)	30164
F	1	*Die-Cut Balsa Sheet (type BF-1343A).	32347
G	1	Body Tube (type BT-50KE) 15"	30364
H	6	Auxiliary Engine Tubes (type BT-20G) 3-1/2"	30324
I	1	*Pattern Sheet (type SP-1343)	83317
J	1	Shock Cord (type SC-1)	85730
K	1	Launch Lug (type LL-2B) 2-3/8" . . .	38178
L	1	Parachute (type PK-12A)	85564
M	1	Shroud Line (type SLT-72)	38237
N	1	Tape Discs (type TD-3F)	38406
O	1	Nose Cone (type PNC-50CA)	71005
P	1	*Decal (type KD-1343)	37149

*Individual items from this part are needed for each kit.

TOOLS AND MATERIALS

In addition to the parts included in this kit you will need white glue (Titebond, Elmer's, or similar household white glue is recommended.), scissors, pencil, fine and extra-fine grit sandpaper, sanding sealer, masking tape, a medium size modeling paint brush, modeling knife with sharp blade, chrome silver spray paint, and chromate green or artillery olive spray paint.



RECOMMENDED ENGINES
A8-3 B4-2 B4-4 B6-2 B6-4 C6-3 C6-5